



Uksehinge reguleerimise juhend

Door hinge adjustment instructions

Vertikaalne reguleerimine ■ Vertical adjustment ■



Horisontaalne reguleerimine ■ Horizontal adjustment ■



Tihendi surve reguleerimine ■ Sealing pressure adjustment ■

